



## **SES 522-06**

## Single cable multiswitch II (SCR) | 5 in $2 \times 2$

Converts the input signals into 4 user bands (according to EN 50494). These are available at both outputs via a built-in output splitter.

Output level SAT (SCR/CSS) 91 dB $\mu$ V  $\pm$  2,0 dB

## **User bands**

UB1: 1331 MHz UB2: 1382 MHz UB3: 1433 MHz UB4: 1484 MHz

Note: Wideband LNB: The AXING single cable multi-switches can be used with a wideband LNB with an oscillator frequency of 10.4 GHz.











